DISPENSER CLEANING / **SANITIZING PROCEDURES**

DAILY

Cleaning the Dispensing Valves



Wash hands with soap and water.



Prepare 2.5 gallons Kay-5® or chlorinebased sanitizer solution in a dedicated bucket. Stir until crystals are dissolved. See packet for instructions and

necessary precautions.



Remove nozzles and diffusers from dispensing



Clean in Kay-5® or chlorine based sanitizer solution with a dedicated nozzle brush and place in sanitizer solution for at least 3 minutes.

DO NOT RUN nozzles, drip pan, etc. through a dishwasher.



Remove nozzles/diffusers from sanitizer solution and let them air dry.



Clean each lower valve body (underneath dispensing valves) with a dedicated brush and Kay-5® or chlorine-based sanitizer solution and wipe with a clean cloth towel.



Wash hands with soap and water. taste a drink from each valve.



Reinstall all nozzles and diffusers once dry. Activate valves for 10 seconds and

Cleaning the Drip Pan



Step 1 Pour 1/2 gallon of the Kay-5® or chlorine-based sanitize solution over cup rest and down drip pan drain.



Step 2 Remove rack. Wipe down inside/outside of the drip pan with a clean cloth towel and Kay-5® or chlorinebased sanitizer solution.

Cleaning the Dispenser If Drop-In:



Step 1 Clean all exterior surfaces of the dispenser, including levers with a clean cloth towel and Kay-5® or chlorine-based



Empty ice bin and pour in a 1/2 gallon of Kay-5® or chlorine-based sanitizer solution



Clean all interior sides with a clean cloth towel and Kay-5 or chlorine-based sanitizer solution. Wipe dry.



Step 4 Clean the ice chute with a dedicated brush and Kay-5® or chlorine-based sanitizer



Follow steps 1 & 2 of Cleaning the Dispensing Valves, then remove nozzle & clean nozzle/ diffuser with a dedicated brush and sanitizer solution. Let them air dry and reinstall nozzle.

WEEKLY

Cleaning the Syrup Connectors



Wash hands with soap and water.



Prepare 2.5 gallons Kay-5® or chlorine-based sanitizer solution in a dedicated bucket. Stir until crystals are dissolved. See packet for instructions and necessary precautions.



Disconnect syrup line from Bag-in-Box.



Soak connectors in a dedicated bucket of Kay-5® or chlorine-based sanitizer solution for 1 minute. It's OK to soak multiple connectors at the same time if they are marked with a flavor label.



Shake BIB connector a couple of times and reconnect syrup lines to correct Bag-in-Boxes.



Document and sign the Dispenser Sanitizing Inspection Log.

MONTHLY

Cleaning the Inside of the Ice Bins



Wash hands with soap and water.



Prepare 2.5 gallons Kay-5® or chlorine-based sanitizer solution in a dedicated bucket. Stir until crystals are dissolved. See packet for instructions and necessary precautions.

Ice Combo



CAUTION!!! Dispenser and ice maker must be UNPLUGGED prior to cleaning.

Ice Combo



Apply sanitizer solution using a dedicated soft, long handle nylon bristle brush to scrub inside of ice bin and chute. Do NOT use a metal

Counter Electric



Condensers Clean condenser fins with a dedicated hard brush:



If air filters are used, clean appropriately



Check water filters to ensure



Maintain product labels for valves...



and syrup lines.

IMPORTANT - Material Handling Info



Use only dedicated ice buckets/scoops when handling beverage ice. Store Properly.



Do NOT store items in ice bin of drop-in dispensers as this could cause contamination.



Keep the ice bin closed when not in use





Do NOT use soap, bleach, detergent, steel wool, scouring pads or abrasives when cleaning dispensers or components.



preparation and handling of sanitizer solution; see package instructions



Call 1-800-Coke (2653) for assistance. Coca-Cola Customer Representatives are available 24/7.

prevent contamination