


Retrofit any U.S. style shank with this flow control faucet and adapter. Adjustments are easy and tamper-proof by using the removable Allen wrench key.



**Note:** Faucet extends 1-7/8" further out from tower than standard beer faucet

<b>Specifications</b>		
Туре	Lagers & Ales Faucet	
Feature	Adjustable Flow Control	
Faucet Washer	27/32" O.D. 21/32" I.D. Thickness;3/32"	
Body	Chrome Plated Brass	
<b>Body Threads</b>	1-1/8"-18 Thread (U.S. Beer Industry Standard)	
Lever Material	303 Stainless Steel	
Lever Threads	3/8"-16 UNC (Unified Coarse Thread)	
Action	Self Closing, spring loaded shaf	
Shaft	Chrome Plated Brass	





## 4933-FCC & 4933-FCG


Prior to attaching the faucet to the dispense tower, please ensure the following:


Ensure the shank adapter is in the correct position.

















On most US tower shanks, the faucet will easily adapt to the shank collar.



In some cases, the shank bore will not allow enough space to accept the torpedo like faucet shank. In this case, the shank adapter needs to be placed on the tower shank first.







Once the Shank Adapter has been tightened to the shank collar, the faucet may be attached.





Once the Faucet has been treaded into the tower shank and adapter, adjust the collar shank in order to straighten the faucet. (Be sure to tighten the collar firmly to ensure a leak proof seal.)



There may be instances where the faucet will not fit older dispense towers.